



Safe Environments
World Wide

For your convenience, record detector #'s here

Detector 1#: _____

Detector 2#: _____

Detector 3#: _____

ALPHA-TRACK (Long Term) Radon Test Kit INSTRUCTIONS

Instructions are furnished to you with specific steps that must be followed. National Safety Products, Inc. cannot provide any warranty remedy to you for any claims, which arise due to the failure to follow instructions.

Detectors should be placed in the basement if one exists. Avoid garages, root cellars, crawl spaces and sumps. If testing more than one area of your home, place the other detector in a frequently used living area, such as a bedroom, living room, kitchen or den. They should be placed near an inside wall at least 30 inches above the floor or at least 8 inches from the ceiling. The detector can be placed on a bookcase, a table, a shelf, or any flat surface or you may wish to hang the detector. Detectors should **NOT** be placed in bathrooms, laundry rooms or porches. **DO NOT** place detectors where they will be exposed to high humidity &/or noticeable drafts from open doors/windows, window, fireplace, heat or air conditioning vents, etc. **DO NOT** place detectors close to the outside walls of the house. **Detectors should be placed where they will not be disturbed during the measurement period.**

After finding a suitable location to place the detector, follow these steps:

1. Remove the detector from the pouch; discard the sorbit (*little cloth looking bag*). Detector is activated when pouch is opened. **(Do not open the detector itself or the test will be invalid) Save the bag, this sheet & mailing carton for return mail.**
2. Write the serial number that appears on the detector (or place bar code) on the **INFORMATION FORM** below along with your name, test address, and email address or phone. **Also, you must write in the date & time that you place your detector!**
3. Write on the **INFORMATION FORM** below the type of room (i.e., basement, living room, bedroom, etc.) where the detector is being exposed. Also write the floor level on which your detector is placed (i.e. basement, 1st floor, 2nd floor, etc.).
4. Three months to twelve months is the recommended amount of time to expose your detector.
5. At the **END** of the test period, place detector back in the bag (or use a zip lock bag), enter the date & time on the **INFORMATION FORM** below. **(necessary for the analysis)**. Please record serial numbers for your reference and ability to retrieve results online.
6. Record the serial number(s) for your reference and ability to retrieve results online. Online results are typically available within 14 to 21 days of the lab receiving the vial(s). **Get Results at: www.TestProducts.com/results**
7. Place the detector(s) & information form in the mailing package → **Affix proper postage, complete the return address and tape the mailing package closed.** **Lab must receive within 7 days from ending the test or results may be invalid.**

Mailing/Shipping Address: **RADON LAB; 11 AWL STREET; MEDWAY, MA 02053**

Get online results typically within 15-21 days of our receiving back in the lab at: **www.TestProducts.com/results**

You should receive your report via eMail if address is provided. Thank You!

National Safety Products, Inc.

www.TestProducts.com

INFORMATION FORM

↑ <i>cut here</i>		INFORMATION FORM	<i>cut here</i> ↑
Send Report To: ↓			Test address: ↓
Name:			Name:
Address:			Address:
City, State, Zip			City, State, Zip
eMail results to:			RMP Cert # (if required):
			<input type="checkbox"/> Check here if this test is a Post Mitigation test
Notes:			
Detector #:	Detector #:	Detector #:	
Floor level:	Floor level:	Floor level:	
Name of room:	Name of room:	Name of room:	
Date & Time Opened:	Date & Time Opened:	Date & Time Opened:	
Date & Time Closed:	Date & Time Closed:	Date & Time Closed:	